





975 Deerfield Pkwy – Buffalo Grove, IL 60089 – Tel (847) 419-9180 – Fax (847) 419-1515
www.transcell.com

INSTRUCTIONS FOR INSTALLING A RATE CARD FOR SPS-10C and SPS-10D Rate Computing Scale

1. Turn the scale off and unplug the AC adapter from the wall outlet.
 2. Turn the scale over so that the bottom is facing up.
 3. Locate the plastic compartment lid.
 4. Remove the lid by pushing the catch and pulling upwards. The rate card is situated directly beneath the lid
 5. To remove, gently ease the rate chip from its socket.
 6. When inserting the new rate card, ensure that the replacement is inserted correctly into the socket. Insert the rate chip into place by pushing down gently.
- NOTE: There is no way to install the rate card backwards. But it may be possible to overlap one or more of the five pins. Please be sure to line up all five pins!
7. Replace the compartment lid, return scale to its upright position and re-connect the AC adapter.
 8. Your scale is ready for use with its new, updated rates.



Push catch and
lift compartment lid



Pull rate card gently
upwards to remove
from socket



975 Deerfield Pkwy – Buffalo Grove, IL 60089 – Tel (847) 419-9180 – Fax (847) 419-1515
www.transcell.com

RELEASE NOTES FOR May 2015 VERSION

All rates and fees have been updated for the May 31, 2015 pricing change.

NOTE: There are still two versions of the update this year:

- First Class Mail Letters – Stamps
- First Class Mail Letters – Metered

USPS Domestic Mail:

1. First-Class Mail® (letters, flats, parcels) - **Retail**
2. Standard Post™ - **Retail**
3. Media Mail® - **Retail**

USPS International Mail:

1. First-Class Mail International® (letters & flats)- **Retail** (*)
2. First-Class Package International Service® (FCPIS) – **Retail** (*)

(*) Only Groups 1-5 are supported

Zone Charts:

- All USPS zone charts are compliant with the June 01, 2015 release.