## GUARDIAN FLOOR SCALE WITH INDICATOR SETUP

- 1. Take scale on pallet to area where it will be used.
- 2. Unpack scale and place it on floor.

NOTE: THE LEVELING FEET ARE TURNED ALL THE WAY IN TO PREVENT DAMAGE DURING SHIPPING. IT IS IMPORTANT YOU SCREW THE FEET OUT A FEW TURNS BEFORE USE.

- 3. Use the feet to level the scale.
- 4. Take cable from underneath scale.
- 5. Connect cable to indicator by connector or hardwire. (Match signals, see manual).
- 6. Plug AC ADAPTER OR AC PLUG into power outlet. *Make sure that the AC voltage appearing at the wall outlet matches the input voltage marked on the AC adapter.*
- 7. Turn indicator on. The indicator will count down then indicate zero weight. If it does not, then press the ZERO key.

You are now ready to use scale. If you see any error message or the scale does not function properly, call 1-800-503-9180.